



SAMOFAR final Meeting

4 – 5 July 2019



SAMOFAR

WP 5 Safety evaluation of the chemical plant

Task 5.1 Evaluation of nuclide inventory at various stages in the chemical plant

Main achievements during the project

P. Souček, A. Rodrigues, D. Rodrigues



European
Commission

European Commission, Joint Research Centre
Directorate G - Nuclear Safety and Security
Nuclear Fuel Safety Unit, Karlsruhe, Germany

Task 5.1 Evaluation of nuclide inventory at various stages in the chemical plant

- 1) **Synthesis of actinide fluorides for the electrochemical studies**
- 2) **Electrochemical study of selected actinides of interest in LiF-ThF_4 melt**
- 3) Experimental study on reductive extraction for clean-up of the fuel salt



Task 5.1 Evaluation of nuclide inventory at various stages in the chemical plant

1) Synthesis of actinide fluorides for the electrochemical studies

- Development of method for **synthesis of high purity AnF_x** of interest (U, Pu, Am)
- Development of method for **synthesis/purification** of sufficient amounts of **pure ThF_4** for preparation of the LiF- ThF_4 melt

1) Synthesis of actinide fluorides for the electrochemical studies

- **Experimental equipment** designed, manufactured, optimised and successfully operated






- Ar glove box, oxygen and moisture content kept < 5 ppm
- The glove box is connected with a pure hydrogen fluoride gas line
- Inconel fluorination reactor (up to 1200°C, 15 g batch, flow-through)
- Non-reactive boats inserts to contain the fluorinated material: BN AX05

Europe-unique installation – possibility to handle gram scale of higher actinides in combination with pure hydrogen fluoride gas

1) Synthesis of actinide fluorides for the electrochemical studies

- **Methods for synthesis of ThF₄, UF₄, PuF₃ and UF₃** developed, optimised, implemented and verified
- **Precursors**
 - High surface stoichiometric UO₂, ThO₂ and PuO₂ (crystal sizes 30-140 nm)
 - Prepared by low-temperature calcination of the oxalates (600-800 C)
- **Synthesis procedure**
 - Solid-gas reaction of the oxides with pure HF gas at elevated temperatures
 - Oxide powder inserted in a BN-AX05 or Nickel boats
 - Reactions are carried out in a flow of HF (50 ml/min) and inert carrier gas Ar (100 ml/min)
 - Molar excess of HF about 3-5




1) Synthesis of actinide fluorides for the electrochemical studies


- **Methods for synthesis of ThF_4 , UF_4 , PuF_3 and UF_3** developed, optimised, implemented and verified

- **Analytical scheme**

- gravimetric (mass balance, typical yield >99 th. %)
- XRD (structure, purity)
- DSC (melting point, purity)
- ICP-MS (metal based purity)



XRD pattern of the synthesized phase pure PuF_3








DSC determination of the melting temperature of the eutectic composition $\text{PuF}_3\text{-LiF}$ (21-79 mol%)

- **Results**

- UF_4 , ThF_4 and PuF_3 synthesised in a very high purity > 99% phase pure, > 99.9% metal base (no traces of oxides detected, purity based on the uncertainty of the analytical methods) in amounts enough for thermodynamic and electrochemical studies
- UF_3 synthesised in purity > 99% phase pure (traces of UO_2 detected by XRD < 0.5 wt.%)

1) Synthesis of actinide fluorides for the electrochemical studies

- **Methods for synthesis of ThF_4 , UF_4 , PuF_3 and UF_3** developed, optimised, implemented and verified





Task 5.1 Evaluation of nuclide inventory at various stages in the chemical plant

2) Electrochemical study of selected actinides of interest in LiF-ThF_4 melt

- **Electrochemical studies of selected actinides** of interest leading to determination of reduction mechanism, diffusion coefficients, standard potentials and **activity coefficients**

2) Electrochemical study of selected actinides


- **Experimental equipment** designed, manufactured, optimised and successfully operated



- Ar glove box, oxygen and moisture content kept < 5 ppm
- HF gas line can be used for the melt purification
- Electrolyser for electrochemistry in molten fluoride media in a vertical furnace (T up to 1000 C, gastight, corrosion resistant)
 - Standard three-electrode set-up / multifunctional purposes


2) Electrochemical study of selected actinides

- **Preparation of the electrochemically pure carrier melts** developed and optimised
 - Mixing of the end members (e.g. $\text{LiF}+\text{CaF}_2$ / $\text{LiF}+\text{ThF}_4$)
 - Slow melting overnight, possibly bubbling of Ar (proven as unnecessary)
 - Bubbling of HF (5-10 ml/min, 60 min) followed by bubbling of Ar to remove the HF



Linear Sweep voltammetry of the pure $\text{LiF}-\text{CaF}_2$ melt before and after HF bubbling, 10 mV/s, $\text{PtO}_2/\text{O}^{2-}$ quasi-ref., 850°C



Cyclic voltammetry on W and Au electrodes
of the pure $\text{LiF}-\text{ThF}_4$ melt
100 mV/s, $\text{PtO}_2/\text{O}^{2-}$ quasi-ref., 650°C



2) Electrochemical study of selected actinides

• Electrochemical behaviour of Th in LiF-CaF₂ melt

- Electrochemical study to determine the activity coefficient of thorium tetrafluoride
- Prove of the electrochemical purity of the synthesised ThF₄
- Cyclic voltammetry: W electrode, 100 mV/s, 0.5 - 2.0 wt.% Th, PtO₂/O²⁻ quasi-ref., 850 C




Linear dependency of the peak current density on the Th concentration

Cyclic voltammetry on W electrode (100 mV/s) of the LiF-CaF₂-ThF₄ melts, PtO₂/O²⁻ quasi-ref., 850 C


2) Electrochemical study of selected actinides

• Electrochemical behaviour of Th in LiF-CaF₂ melt

- Activity coefficient determined from cyclic voltammetry: $\gamma(\text{ThF}_4) = 9.88 \cdot 10^{-3}$
- Cyclic voltammetry: W electrode, 100 mV/s, 1.0 wt.% Th, PtO₂/O²⁻ quasi-ref., 850 C




Li(I)/Li redox system:



$$E_{(\text{LiF}/\text{Li})} = E_{\text{LiF}/\text{Li}}^0 + \frac{2,3RT}{F} \log \frac{a(\text{LiF})}{a(\text{F}^-) a(\text{Li})}$$

Th(IV)/Th redox system:



$$E_{(\text{ThF}_4/\text{Th})} = E_{(\text{ThF}_4/\text{Th})}^0 + \frac{2,3RT}{4F} \log \frac{a(\text{ThF}_4)}{a(\text{F}^-)^4 a(\text{Th})}$$

$$\Delta E = E_{\text{LiF}/\text{Li}}^0 + \frac{2,3RT}{F} \log \frac{a(\text{LiF})}{a(\text{F}^-) a(\text{Li})} - E_{(\text{ThF}_4/\text{Th})}^0 - \frac{2,3RT}{4F} \log \frac{a(\text{ThF}_4)}{a(\text{F}^-)^4 a(\text{Th})}$$

$$a(\text{ThF}_4) = x(\text{ThF}_4) \gamma(\text{ThF}_4)$$

$$\Delta E = -0.452 \text{ V} \quad a(\text{LiF})=0.798 \quad x(\text{ThF}_4) = 1.76 \cdot 10^{-3}$$

$$a(\text{ThF}_4) = 1.74 \cdot 10^{-5}$$

$$\gamma(\text{ThF}_4) = 9.88 \cdot 10^{-3}$$

Cyclic voltammetry on W electrode (100 mV/s) of the LiF-CaF₂-ThF₄ melts, PtO₂/O²⁻ quasi-ref., 850 C

Summary

- **Synthesis of pure actinide fluorides**

- Europe **unique experimental set-up** allowing fluorination of actinides in 10 g scale using **pure HF gas**
- Methods for **synthesis of pure UF_4 , UF_3 , ThF_4 and PuF_3** established
- **Analytical scheme developed** based on combination of XRD, DSC and ICP-MS
- Products were proven to have **excellent purity** (> 99% phase pure, > 99.9% metal base)

Electrochemistry in molten fluoride salts

- **Experimental set-up** developed, installed and optimised
- Methods for **preparation and purification of carrier melts LiF-CaF_2 and LiF-ThF_4** developed and proven effective
- **Basic electrochemical studies of Th in LiF-CaF_2 melt** successfully carried out and used to check purity of the synthesised ThF_4 and the activity coefficient of ThF_4 in this melt was determined
- Electrochemical studies in **LiF-ThF_4 melt** have started

Thank you for your attention

Stay in touch



EU Science Hub: [*ec.europa.eu/jrc*](http://ec.europa.eu/jrc)



Twitter: [*@EU_ScienceHub*](https://twitter.com/EU_ScienceHub)



Facebook: [*EU Science Hub - Joint Research Centre*](https://www.facebook.com/EU_Science_Hub_-_Joint_Research_Centre)



LinkedIn: [*Joint Research Centre*](https://www.linkedin.com/company/joint-research-centre)



YouTube: [*EU Science Hub*](https://www.youtube.com/EU_Science_Hub)